

remote dashboard





Hey, thanks for joining to REBELS community!

Due to new configuration process, there is a unique model factor you'll need to setup.

Check out FAQ on official website: scooter-unlock.eu (scooter-rebel.eu) for known model factor settings.

Please read and follow instructions below:

1. navigate to your device (smartphone, tablet, watch, computer) wifi settings
2. connect to network called (e.g.): REBEL-1234567 with your unique password (you can find it on QR sticker, **save it!**)
3. after successful connection, open website address 192.168.4.1
4. Set your „Model factor” and „Dashboard factor” according to your ESC model or speed preferences
5. Press „Vehicle power” button to turn on scooter.



If you connection time is slow, configure your connection manually, set:
IP address: 192.168.4.2 **Gateway: 255.255.255.0**
Router IP: 192.168.4.1 **DNS: 192.168.4.1**